



Samsung Galaxy S II Teardown

A main body teardown of the Samsung Galaxy S II

Written By: Devon Crump



Step 1 — Remove back of phone



- Find the small divot and use a plastic tool or your fingernail to remove the plastic cover off the back. This step requires no removal of screws.

Step 2



- Remove the 11 screws from the back of the phone. This will require a Philips #00 screwdriver.

Step 3



- Separate the screen and internals from the casing on the back by using a small plastic tool or your fingernail to get under the screen and lift it up. Once it has been unclipped, pull the 2 completely apart.

Step 4



- The back of the screen should look like this. From here, we have access to any fixes that would need to be made for the phone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 02:48:10 AM.